

SMS Command List JC200 V6.0

Command Category	Command Function	Header	Format	Comment
Command untuk [VERSION]KM8216_EN_USB_V5.2_20220111				
Device Function	Add SOS Number	SOS	SOS#666666#A#Phone number#Phone number#Phone number	If only one phone number need to be added, other phone numbers should to be written 0; E.g.: SOS#666666#A#10086#0#0
	Query SOS Number	SOS	SOS#666666	/
	Delete SOS Number	SOS	SOS#666666#D#Phone number#Phone number#Phone number	If only one phone number need to be deleted, other phone numbers should to be written 0; E.g.: SOS#666666#D#10086#0#0
	Set APN	APN	APN#666666#<name>#<capn>#<mcc>#<mnc>#<type>#<proxy>#<port>#<user>#<server>#<password>#<mmsc>#<mmsproxy>#<mmsport>#<numeric>	Generally: we need APN, MCC and MNC value: APN#666666#APNname#APNname#MCC#MNC E.g.: APN#666666#unim2m.gzm2mapn#unim2m.gzm2mapn#460#06
	Change Roaming State	ROAMING	ROAMING#666666#A	A=ON, OFF; E.g.: ROAMING#666666#ON
	Check Version	VERSION	VERSION#666666	/
	Paramter Check	PARAM	PARAM#666666	/
	PING TCP Server by Interval	PING	PING#666666#<A>#<M>	A=ON, OFF; M=10- (Value of the interval,smallest is 10s) E.g.: PING#666666#ON#10 PING#OFF
	Status Check	STATUS	STATUS#666666	GPRS: Connected;GSM Signal Level: Strong;GPS: Successful Positioning,SVS Used in fix: 9(11),GPS Signal Level: 13,14,19,16,29,22,24,17,24;ACC: ON
	Factory Setting	RESTORE	RESTORE#666666	/
	Reboot Device	REBOOT	REBOOT#666666	/
	Query TCP Server	SERVER	SERVER#666666	/
	Query HTTP server	UPLOAD	UPLOAD#666666	/
	Change Password	PASSWORD	PASSWORD#666666#	E.g.: PASSWORD#666666#123456
	Recover Password	RECOVER	RECOVER#999999	Recover to 666666;
Overspeed	SPEED	SPEED#666666#(ON/OFF)#(period)#(speed value)	E.g: Deive speed over 80km/h for 10s : SPEED#666666#ON#10#80	
Event Alarm	Turn ON Crash Alarm	CRASHALM	CRASHALM#666666#A#M	A=ON;M=1,2,3 (Sensitivity Level: 1=low, 2=middle, 3=high); E.g.: CRASHALM#666666#ON#1
	Turn Off Crash Alarm	CRASHALM	CRASHALM#666666#A	A=OFF; E.g.: CRASHALM#666666#OFF
Integrate Version Firmware:				
Device Function	OTA Upgrade	UPDATE	UPDATE#666666#(File address)	UPDATE#666666#http://www.test.com/update.zip
	Set TCP Server	SERVER	SERVER#666666#(1 Or 0)#(domai Or IP)#port	E.g.: SERVER#666666#1#gpsdev.car-matrix.com#21100 or SERVER#666666#0#47.89.58.215#21100
	Set RTMP Server	RSERVICE	RSERVICE#666666#(RTMP Server Address)	RSERVICE#666666#demo.easydss.com:10085/live/jimi001
	Set HTTP Server	UPLOAD	UPLOAD#666666#(HTTP Server Address)	UPLOAD#666666#http://resource.jimicloud.com/upload